

MAK2

A2
B2
C2
A3
B3
C3

LAST
+U
Masse
NFRX
SQS
NFTX



LS1000

C1
A5
A1
A3
A8
A4
A7

LS1000

C1
A5
A1
A3
A8
A4
A7

LAST
+U
Masse
NFRX
SQS
NFTX



A4
B4
C4
A5
B5
C5

LS1000

C1
A5
A1
A3
A8
A4
A7

LAST
+U
Masse
NFRX
SQS
NFTX



A6
B6
C6
A7
B7
C7

LS1000

C1
A5
A1
A3
A8
A4
A7

LAST
+U
Masse
NFRX
SQS
NFTX



A8
B8
C8
A9
B9
C9

LS1000

C1
A5
A1
A3
A8
A4
A7

LAST
+U
Masse
NFRX
SQS
NFTX



A10
B10
C10
A11
B11
C11

LS1000

C1
A5
A1
A3
A8
A4
A7

LAST
+U
Masse
NFRX
SQS
NFTX



A12
B12
C12
A13
B13
C13

Verschaltung für Versorgung, NF, SQS
und Sendertastung zwischen MAK2
und den einzelnen LS1000 Karten

Relaissteuerung bis 6x2 Relaisfunkstellen

TITLE: ltg0060

Document Number:

REV:

Date: 19.11.2002 13:21:04

Sheet: 1/1